CR

SERIES

TECHNICAL MANUAL

VERSION 1.0
December, 1998

Copyright : 1998 RISO Kagaku Corporation
All Rights Reserved. This Technical Manual was prepared and written for the exclusive use of RISO International Group Certified Dealers. Reproduction and/or transmittal of this material in any form or by any means, including photocopying or recording of the information is strictly prohibited without the consent of a member of RISO International Group.

RISO INTERNATIONAL GROUP

RISO KAGAKU CORPORATION (JAPAN)
RISO, INC. (U.S.A.)
RISO EUROPE LIMITED (U.K.)
RISO HONG KONG (HONG KONG)
RISO UK (U. K.)
RISO THAILAND LIMITED (THAILAND)
RISO DEUTSCHLAND GMBH (GERMANY)
RISO FRANCE (FRANCE)
RISO IBERICA (SPAIN)
RISO CANADA (CANADA)
RISO CHINA (HONG KONG)
RISO AFRICA (SOUTH AFRICA)

CONTENTS

CHAPTER 1: MAINTENANCE

1. Preface 1-1
   CAUTION 1-2
   WARNING 1-3
2. WORK PRECAUTIONS 1-4
3. Exterior Cover Removal
   > Front cover 1-5
   > Master removal upper cover 1-5
   > Master removal lower cover 1-5
   > Back cover 1-6
   > ADF cover 1-6
   > ADF unit cover 1-6
   > Master making unit cover 1-6
   > Drum cover 1-6
4. Opening PCB Bracket Frames
   1. Main PCB Bracket Frame 1-7
   2. Power Supply PCB Bracket Frame 1-8
   3. Main PCB and Power Supply PCB Bracket Frames 1-9

CHAPTER 2: MACHINE SUMMARY

1. Specifications
   1. CR1610 2-1
   2. CR1630 2-2
2. Cross Sectional Diagram 2-3
3. Machine Operations 2-4
4. Paper Feed and Receiving 2-5
5. Master Removal and Feed 2-6
6. Maintenance Call 2-7

CHAPTER 3: MAIN DRIVE SECTION

1. Theory of Operation
   1. Main Drive 3-1
   2. Main Motor Safety Switches 3-2
   3. Drum Positions 3-3
   4. Drum Locking System 3-5
2. Removal and Assembly
   1. Main Motor Unit 3-7
   2. Intermediate Gear 3-9
   3. Master Removal Unit Safety Switch 3-10
   4. Master Making Unit Safety Switch 3-11
   5. Drum Safety Switch 3-12

CHAPTER 4: FIRST PAPER FEED SECTION

1. Theory of Operation
   1. Paper Feed Tray Elevation 4-1
   2. First Paper Feed Drive Mechanism 4-3
   3. Paper Pickup System 4-5
   4. Paper Feed Pressure Select System 4-6

2. Removal and Assembly
1. Paper Feed Tray Unit 4-7
2. Paper Detection Sensor 4-8
3. Scraper and Pickup Rollers 4-9
4. Stripper Pad 4-10
5. Upper Limit Sensor 4-11
6. Paper Feed Clutch 4-12
7. Scraper Assembly 4-13
8. Elevator Motor Unit 4-14
3. Adjustment
1. Upper Limit Sensor Position 4-15
2. First Paper Feed Distance (OFF Timing of Paper Feed Clutch) 4-16

CHAPTER 5: SECOND PAPER FEED SECTION

1. Theory of Operation
1. Second Paper Feed Drive Mechanism 5-1
2. Vertical Print Position 5-3
2. Removal and Assembly
1. Load Spring 5-5
2. Timing Cam 5-6
3. Sector Gear 5-7
4. Print Positioning Unit 5-8
5. Print Positioning Pulse Motor 5-9
6. Paper Guide Plate 5-10
7. Paper Sensor 5-12
8. Timing Roller 5-13
3. Adjustment
1. Timing Cam Mounting Position 5-15

CHAPTER 6: PRESS SECTION

1. Theory of Operation
1. Press Mechanism 6-1
2. Removal and Assembly
1. Pressure Roller 6-5
2. Pressure Lever Ass'y 6-6
3. Pressure Shaft Ass'y 6-8
4. Pressure Solenoid 6-9
3. Adjustment
1. Pressure Lever Ass'y Position 6-11

CHAPTER 7: PAPER EJECTION SECTION

1. Theory of Operation
1. Paper Ejection Mechanism 7-1
2. Paper Separation Mechanism 7-3

2. Removal and Assembly
1. Suction Unit 7-5
2. Transfer Belt 7-6
3. Suction Fan 7-8
4. Paper Ejection Motor 7-8
5. Separation Fan Unit 7-9
6. Separation Fan 7-10
7. Paper Receiving Sensor 7-10
8. Separator 7-11
9. Paper Receiving Tray 7-13
3. Adjustment
1. Separator Position 7-15

CHAPTER 8: DRUM SECTION

1. Theory of Operation
1. Master on Drum (in printing) Check Mechanism 8-1
2. Drum Set Check Mechanism 8-2
3. Ink Cartridge Set Check Mechanism 8-3
4. Ink Cartridge Setting Mechanism 8-4
5. Drum Inserting Block Pin Mechanism 8-5
6. Ink Supply Mechanism 8-6
7. Drum Idling Mechanism 8-8
8. Squeegee Roller Rotation Mechanism 8-10
2. Removal and Assembly
1. Screen 8-11
2. Drum Body 8-12
3. Ink Sensor PCB 8-14
4. Cartridge Holder and Cartridge Set SW Cover 8-15
5. Cartridge Set SW PCB 8-15
6. Cartridge Holder Base 8-16
7. Squeegee Roller 8-17
8. Drum Support F & Drum Support R 8-19
9. Ink Pump Unit / Drum Set Sensor 8-22
10. Inking Motor 8-23
11.Slider Link 8-24
12. Cartridge Set Lever Unit 8-25
3. Adjustment
1. Squeegee Gap 8-26
2. Squeegee Pressure Balance 8-27
3. Ink Blocking Plate Position 8-28

CHAPTER 9: PAPER JAM

1. Theory of Operation
1. Paper Jam at First Paper Feed Area 9-1
2. Paper Jam at Second Paper Feed Area 9-2
3. Paper Jam on the Drum 9-3
4. Paper Jam at Paper Receiving Area 9-4
5. Print Start Timing Chart 9-5
6. During the Printing Timing Chart 9-6
7. Print Stop Timing Chart 9-7

CHAPTER 10: MASTER CLAMP SECTION

1. Theory of Operation
   1. Clamp Unit Home Positioning Mechanism 10-1
   2. Clamp Plate Master Release Mechanism 10-3
   3. Clamp Plate Master Clamp Mechanism 10-5
2. Removal and Assembly
   1. Clamp Unit 10-7
   2. Clamp Motor 10-8
   3. Clamp Sensor A 10-8
   4. Clamp Sensor B 10-8

CHAPTER 11: MASTER REMOVAL SECTION

1. Theory of Operation
   1. Master Removal Unit Home Positioning Mechanism 11-1
   2. Master on the Drum (before master removal) Check Mechanism 11-3
   3. Clamp Plate Master Release Mechanism 11-5
   4. Master Removal Mechanism 11-7
   5. Disposed Master Compressing Mechanism 11-9
   6. Master Disposal Box Set Mechanism 11-12
2. Removal and Assembly
   1. Master Removal Unit 11-13
   2. Compressing Motor 11-15
   3. Master Removal Motor 11-16
   4. Master Removal Sensor 11-18
   5. Master Full Det. Sensor 11-18
   6. Master Compressing Sensor 11-18
   7. Pulley Shaft 11-19
   8. Vertical Transport Roller (up) 11-19
   9. G-Belts on Vertical Transport Roller (up) 11-19
   10. Master Removal Hook 11-20
   11. Master Sensor 11-20
   12. Vertical Transport Roller (down) 11-21
   13. G-Belts on Vertical Transport Roller (down) 11-21
   14. Master Compress Plate 11-22

CHAPTER 12: IMAGE SCANNING SECTION

1. Theory of Operation
   1. Original Loading Mechanism 12-1
   2. Original Scanning Mechanism 12-3
   3. Image Scanner 12-5
2. Removal and Assembly
   1. Original Feed Solenoid 12-7
   2. Image Scanner Unit 12-8
   3. Original Detection Sensor 12-9
   4. Original IN Sensor 12-9
   5. Stripper Roller 12-10
   6. Pickup Roller 12-10
   7. Stripper Pad Ass'y 12-11
   8. Read Pulse Motor 12-12

CHAPTER 13: CUTTER SECTION

1. Theory of Operation
   1. Cutter Home Positioning Mechanism 13-1
   2. Cutting Mechanism 13-3
2. Removal and Assembly
   1. Cutter Unit 13-5

CHAPTER 14: MASTER MAKING SECTION

1. Theory of Operation
   1. Master Making 14-1
   2. Thermal Power Safety Switches 14-3
2. Removal and Assembly
   1. Write Roller 14-5
   2. Thermal Print Head (TPH) 14-6
3. Adjustment
   1. Thermal Power of Thermal Print Head 14-7

CHAPTER 15: MASTER CLAMPING / LOADING SECTION

1. Theory of Operation
   1. Master Making Unit Set Mechanism 15-1
   2. Master Tension Plate Home Positioning Mechanism 15-2
   3. Master Positioning Mechanism 15-4
   4. Master Feeding Mechanism 15-6
   5. Clamp Plate Master Clamp Mechanism 15-8
   6. Master Loading on the Drum Mechanism 15-10
   7. Master Tension Plate Lifting Mechanism 15-12
   8. Master Advancement after Master Cutting 15-14
2. Removal and Assembly
   1. Master Making Unit 15-17
   2. Master Making Unit Set Switch 15-19
   3. Write Pulse Motor 15-20
   4. Master Making Upper Unit 15-21
   5. Master Positioning Sensor 15-23
   6. Master Tension Plate Sensor 15-24
   7. Master Loading Clutch 15-25
   8. Master Tension Plate Solenoid 15-25
   9. Master End Sensor 15-26

APPENDIX

Electrical Components ..... APX(0)-1
Test Mode ..... APX(1)-1
Memory Switches (Test Mode) ..... APX(2)-1
Users Mode ..... APX(3)-1
Advice Displays (Call Service Messages) ..... APX(4)-1
Description of PCBs ..... APX(5)-1